

1-Year Manufacturer Warranty

Please note: The warranty is ONLY valid AFTER your registration.

CONTACT US


We are always ready to help if you have any concerns with the purchase.

WAX WARMER KIT

User Manual



Hey beautiful! Please don't start in a hurry. Read this before starting your journey to silky-smooth.



INTRODUCTION

Congratulations on the purchase of this Waxing Kit. You have selected a high-quality product. Please familiarize yourself with all operating and safety instructions BEFORE using this appliance.

INTENDED USE

This appliance has been designed exclusively for hair removal of legs, armpits and the bikini zone on the human body. The warmer is suitable for use for all wax types (including canned wax). It is intended solely for use in private households.

TECHNICAL DETAILS

Voltage	110 - 240 V ~ (AC), 50 - 60 Hz
Power consumption	50 W
Capacity	500 ml



This product has been tested to comply with EMC Directive (2014/30/EU), LVD Directive (2014/35/EU), and FCC standards.

* During the first few minutes of initial use, you may notice a slight odor. This is normal and will quickly disappear.

WARNING:

▲ Please note that hair removal (of any kind!) can cause trauma to the skin, and normal skin reactions may occur such as redness, swelling, tenderness, etc.

- ▶ Before waxing, do a 24-hour patch test to see how skin reacts.
- ▶ Beware of burns. Wax can reach high temperature and cause burn injuries!
- ▶ Do not wax the area with redness, inflammation, swelling, open wounds, burns, eczema or psoriasis.
- ▶ Please consult with your doctor before use if you are susceptible to allergic reactions or have any health concerns.



IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed including:
READ ALL INSTRUCTIONS BEFORE USING.

DANGER – To reduce the risk of **ELECTROCUTION**:

1. Always unplug this appliance immediately after using it.
2. Connect this appliance to a properly grounded outlet only.
3. Do not use while bathing or showering.
4. Do not place or store appliance where it may fall or be pulled into a tub or sink.
5. Do not immerse the appliance in water or other liquids!
6. NEVER reach in to get an appliance that has fallen into water. Make sure you don't stand in water and unplug immediately with electrically insulated gloves.



WARNING! **RISK OF ELECTROCUTION!**



NEVER use this appliance near a bath tub, shower or other vessels filled with water.

CAUTION – To reduce the risk of fire, burns, electric shock or any other injury:

1. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, provided that they are under supervision or have been told by a responsible person regarding use of the appliance in a safe way and understand the potential risks involved.
2. Always test before use: apply hot wax on a small area of the skin for warmth and possible skin reactions.
3. Use this appliance on a level, heat-resistant surface.
4. Do not leave the appliance unattended while it is being operated or plugged in.
5. Use this appliance only for its intended use. The use of attachments not recommended by the manufacturer may cause hazards.
6. Do not allow children to play with the appliance.
7. Close supervision is necessary when this appliance is used near children or invalids.
8. Unplug from outlet when not in use. Allow cooling before handling, cleaning or storing the appliance.
9. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged in any manner or dropped into water.
10. Keep the cord away from hot or heated surfaces. Do not wrap the cord around the appliance.
11. Do not drape the cord over a counter or a tabletop in such a manner that it can be pulled on by a child or tripped over unintentionally
12. The use of an extension cord is not recommended.

QUICK-START GUIDE

1. READY

Hair should be 1/4 inch long to wax effectively. Your skin should be clean and dry.

2. SET

Put wax into the wax warmer and allow the beads to melt until it's the consistency of honey.

3. TEST

Test a small amount of melted wax on the inside of your wrist to make sure that it's not too hot.

4. APPLY

Using the applicator, apply the wax in the direction of hair growth. Work in small manageable sections.

5. COOL

Wait for 30-45 seconds and allow the wax to harden. It's ready to remove as soon as it's no longer sticky to the touch.


6. PULL

Hold skin taut. Flick the edge of the wax-up and pull quickly in the opposite direction of hair growth.

USER INSTRUCTIONS

HOW TO USE THE WAX WARMER

1. Fill the removable pot with 3.5-11 oz wax beads.
2. Place the pot into the designated insert within the warmer.
3. To melt wax quickly, place the lid on and turn the dial clockwise to max heat.
4. After the wax is melted into a liquid consistency, adjust to your desired temperature.



You'll see the indicator light turn from red to off when the desired temperature is reached.

* The temperature will remain constant, meaning the warmer will automatically turn on to heat wax when it drops below the desired temperature.

HOW TO USE THE WAX BEANS

Application of hard wax depends on the area to be waxed and how coarse the hair is.

To perform an effective result, it's recommended that you follow the instructions below:

1. Allow the wax to melt completely. We recommend a temp between 150-180°F.
 2. The best indication that your wax is the right applicable temperature is when it resembles the consistency of thick honey.
 3. Always use with caution. It's important to test a small amount of melted wax on the inside of your wrist before application.
 4. Make sure your skin is completely dry before waxing. Apply some baby powder to soak up any excess moisture if necessary.
 5. Using the applicator, apply wax in direction of hair growth. Use firm pressure to ensure each hair is shrink-wrapped with wax.
 6. Wait 30-45 seconds and allow the wax to harden.
 7. It's ready to be removed as soon as it's no longer sticky to the touch. Hold skin taut. Flick the edge of the wax up and pull quickly AGAINST direction of hair growth.
 8. Repeat over different sections until the desired area is soft, silky hair-free.
- READ ALL INSTRUCTIONS BEFORE USING.

EASY CLEANUP OF WAX POT

Note: You don't need to clean the wax pot after each use!

The left-over wax can be melted and reused for application next time.

To clean your pot, please ensure that the appliance is unplugged but still warm.

Use cotton muslin strips or paper towels to wipe clean. You can also use a wax warmer cleaning solution or a small amount of oil.

PRO TIPS

To achieve a more effective hair removal result, we strongly recommend you to:

- ▶ Apply wax in direction with hair growth and remove in opposite.
- ▶ Hydrate and exfoliate a day or two prior to waxing.
- ▶ On the day of waxing, avoid using any lotions or creams.
- ▶ When removing, pull the wax parallel and close to your waxed skin.
- ▶ Avoid undue sun exposure for 24-48 hours.
- ▶ Exfoliate after at least 24 hours to help prevent ingrown hairs.
- ▶ Get on a regular waxing schedule and avoid shaving in between waxing.


APPLICATION



Apply wax following direction of hair growth



Remove AGAINST the hair growth



LOCATION

*** Please treat only small areas at once if you are new to waxing.**

EYEBROWS

- Brush, shape, and cut brows before waxing.
- Use the mini brow applicator and wax in small sections for precise results.
- Use Vaseline or coconut oil as a protective barrier over any brow hair you don't want the wax to stick to.
- Be cautious that wax doesn't drip into eyes.

UPPER LIP, CHIN & CHEEKS

- Wax your upper lip in three sections: right, left, and center.
- Facial hair can grow in swirls, so stick with small sections.

UNDERARMS/LEGS

- Note the hair growth pattern before you begin. You may need to wax in several sections if your armpit hair grows in multiple directions.
- Applying against hair growth may be necessary to completely pick up all the hair.

BIKINI & BRAZILIAN

- Have a mirror on hand.
- Sit on the floor or on your bed with a towel under you, with the soles of your feet touching each other.
- Start waxing from the outside edges of the hairline, where your hair is thinnest and less sensitive.
- Take note of the way your hair grows. Work in small manageable sections.
- Hold your skin taut while removing wax, especially in sensitive areas prone to bruising.

TROUBLESHOOTING Q+A

Why didn't the wax remove all my hair?

- The hair was too short. The ideal length for wax to grip and remove hair from root is 0.25inch-0.75inch (0.6cm-2cm).
- The wax was too cool. Heat the wax until it's the consistency of honey.
- Sometimes hair grows in multiple directions. Try a second application while applying the wax in an alternate direction.
- If hair remains after 2-3 passes, it's best to clean up with tweezers.
- Apply more pressure with the applicator. Firm pressure ensures each hair is shrink-wrapped with wax.

Why is wax residue left on my skin?

- The wax was applied too thin. Use a little more. Apply it about a nickel thick.
- The wax was applied unevenly. With practice you will avoid this issue.
- Use the AFTER-Wax treatment oil to remove any residue.

How long should my hair growth be?

We advise waiting until your hair is at least ¼ inch in length (around the size of a grain of rice). If your hair is too short, there won't be enough length for the wax to grip it, and your results won't be successful.

Are there any concerns I should be aware of?

- Avoid applying wax to moles, warts, mucous tissue, sunburned or irritated skin.
- Do not use wax if you're taking Retin-A or Accutane.
- Do not wax after plastic surgery or a chemical peel until approved by a physician.
- Avoid sun and hot water for 8 hours after use.

Do I need cloth strips?

Nope. No cloth strips are needed with hard wax.

Is that normal If the wax warmer auto turns on and off?

This wax warmer has AUTOMATIC POWER OFF FUNCTION -- When wax warmer in a hot temperature, indicator light will turn down automatically and turn on when temperature is low.

1-YEAR MANUFACTURER WARRANTY

Your product will either be repaired or replaced if any defect in material or workmanship occurs within ONE year from the date of purchase. The repair or replacement of a product does not signify the beginning of a new warranty period.

Please note this warranty does not apply if:

1. The product has been damaged by accident, abuse or mishandling.
2. The product has been used in a way that does NOT follow the Wax Warmer User Manual.
3. Units subjected to unauthorized repair.

Manufacturer:

ZHONGSHAN CITY PINK DIAMOND COSMETICS TECHNOLOGY CO., LTD.

U.S. FDA Establishment ID: 1009665

Address: Building 11, No.11, Gangbao Road
Tongmao Industrial West Avenue, Dongsheng Town
Zhongshan City, Guangdong Province, P. R. China
Email: pinkdiamond2019@hotmail.com

Authorized Representative

* Please note that the following address is not the service address.

EC	REP	EUBRIDGE ADVISORY GMBH Virginia Str. 2 35510 Butzbach, Germany eubridge@outlook.com
----	-----	--

UK	REP	TANMET INT'L BUSINESS LTD 9 Pantygraigwen Road, Pontypridd, Mid Glamorgan, CF37 2RR, UK tanmetbiz@outlook.com
----	-----	--

Disposal



Please DO NOT dispose of the appliance in your normal domestic waste. This product is subject to the provisions of the WEEE Directive (2012/19/EU). Disposal can take place through an approved disposal center at your community.

Please contact your local community or municipal authorities if you have any doubt about how to dispose of the worn-out product.



The environmentally friendly packaging can be easily disposed of at any of your local recycling facility.